

Notes: When operate on Keypad, please don't press key too quickly, press each key one by one to ensure each key is really pressed down.

Note: if want to delete PIN user in future(for example, the person doesn't work for you, need to delete his/her open privilege), During the enroll process, please write down and record each user's USER ID)

How to add PIN user?

User ID is 1~2000, it's better you can use from 1, continuously, each number for a person.

ensure user ID is not used for other person when you plan to use this ID for new person

For example, I have totally 200 users.

Person: John, user ID 1, Password: 345829 to open door

...

Person: Jack, User ID: 100, password 4527 to open door

To program John, steps as below:

Press: *888888#

press 1 (to add user)

press 1 # (1 here is user ID)

Press 345829 #

press * * to quit

Now press 345829 then #, can open lock.

To program Jack, steps as below:

Press: *888888#

press 1 (to add user)

press 100 # (100 here is user ID)

Press 4527 #

press * * to quit

Now press 4527 then #, can open lock

How to delete PIN user?

User ID is 1~2000, User ID is assigned to different users at above enroll process.

Press: *888888# (enter programming mode)

press 2 (to delete user)

press 23 # (23 here is user ID, so need to record some where when you enroll the user, so that you know which user ID is who)

press * * to quit

with above steps, the user(which user ID=23) will be deleted.