

## [Quick Program guide]

---

email: [be.seen@hotmail.com](mailto:be.seen@hotmail.com)

skype: pablochen.1996

We bring value to a lot projects during the past 20 years, also save a lot cost for many customers.

If any problem, please **don't return directly, that will bring big loss to us.** I do support with my heart, Contact me for solution.

Any question is good question, we have over 20 years experience, Our support is for ever.

**CREATE SECURITY FOR YOU**

## Contents

|                                                        |   |
|--------------------------------------------------------|---|
| 1. Quick Trial .....                                   | 2 |
| 1.1 Quick try: Enroll Fingerprint.....                 | 2 |
| 1.2 Quick try: Enroll Fingerprint with User ID.....    | 2 |
| 1.3 Quick Try: Enroll PIN Code/Password. ....          | 2 |
| 2. Official Do program for all users .....             | 3 |
| 2.1 Want to delete all users and start from Fresh..... | 3 |
| 2.2 About user ID Number .....                         | 3 |
| 2.3 How to Delete Fingerprint User.....                | 4 |
| 2.4 How to delete User <i>by User ID Number</i> .....  | 4 |
| 3. Want to change the default program code .....       | 4 |

## 1. Quick Trial

After wire and power on the system (**we have detail wire diagram and video for how to wire**), Now we can do a **quick trial**.

### 1.1 Quick try: Enroll Fingerprint

Press: \* **123456 #** (here **123456** is default master code)

Press: **1**

Punch the **same** fingerprint for 2 times

press \* to quit programming mode, the LED will be solid Red then.

**Now Punch the fingerprint, can open lock, also the LED of Keypad become to Green for a few seconds.**

### 1.2 Quick try: Enroll Fingerprint with User ID

Press: \* **123456 #** (here **123456** is default master code)

Press: **1**

Press: **100#** ( **100** here is user ID number, the user ID number range is **1~1000** )

Punch the **same** fingerprint for 2 times

press \* to quit programming mode, the LED will be solid Red then.

**Now Punch the fingerprint, can open lock, also the LED of Keypad become to Green for a few seconds.**

### 1.3 Quick Try: Enroll PIN Code/Password.

For example, Person: John, user ID number: 120, Password: 8899 to open door

To program John, steps as below:

Press: \* 123456 # (here 123456 is default master code)

Press: 1

Press: 120# ( 120 here is user ID number, the user ID number range is 1~1000 )

Press 8899 #

press \* to quit

**Now press 8899 # , can open lock.**

## 2. Official Do program for all users

### 2.1 Want to delete all users and start from Fresh

Previously, maybe do some trial, now do official program, suggest that remove all users and begin from fresh stage, **the steps** are:

Press: \* 123456 # ( enter programming mode )

press 2 (to delete user)

press 123456 # ( 123456 is the programming code )

press \* to quit

**Now all enrolled users( Fingerprint or pin code, all deleted)**

### 2.2 About user ID Number

This device support 1,000 users.

the user ID is from 1~1000

PIN code is 4-6 digits.

**Notes: Possibly a person will not work for you in future, you need to delete his/her open privilege. When do the enroll programming, we suggest you assign unique user ID for each user and save these information, it will be easy to delete user. For example, the format can be:**

Jon( fingerprint user ID: 100, PIN user ID: 110)

Peter(Fingerprint user ID: 101, no PIN enrolled)

Mary( PIN user ID: 111, no fingerprint enrolled for her)

...

## 2.3 How to Delete Fingerprint User

Press: \* 123456 #, the red LED will flash slowly, This is to enter program mode.

Press: 2

Punch the fingerprint

If success, the led color become to orange

Then press \* to quit programming mode, the led will be red always.

## 2.4 How to delete User *by User ID Number*

Take this as example:

John( PIN user ID: 120, PIN code is: 8899)

Press: \* 123456 #, the red LED will flash slowly, This is to enter program mode.

Press: 2

Press: 120# ( 1100 here is user ID)

If success, the led color become to orange

Then press \* to quit programming mode, the led will be red always.

## 3. Want to change the default program code

Firstly, enter programming mode by: \* Master code #, 123456 is the default master code

then press: 0 new code # new code #

for example, new code is: 987654, you should: 0 987654 # 987654 #

Then press \* to quit program mode.