
Step1: Check the controller as below:



Step2: If the communication have problem, will display below window, press as below:

