

I will **support you for ever** with my nearly 20 years experience.

1. If you prefer email, I will do email support.
2. If you want phone support, I can call you(**Please tell me your phone number**)
3. Also can do teamviewer support to remotely connect to your computer to guide you, to provide live training for you.

System idea is: The long range reader read tag number, pass to the metal keypad device, the keypad device acts as master controller and will do verify and release relay to open barrier or lock.

1. For how to **wire the system**:

- a) video is: <https://youtu.be/BEjweG0CNNE>
- b) Wire diagram is: <https://beseencontrol.com/K80LR/XiaoK80LReader.jpg>

- **Long reader is powered on by it's own power adapter.**
- **Long Reader's grey wire, connect to GND(black wire) of Keypad device.**
- **Long Reader's yellow wire, connect to D0(green wire) of keypad device.**
- **Long Reader's deep green wire, connect to D1(white wire) of keypad device**

2. The main program steps is from below link:

<http://beseencontrol.com/K80LR/1.Steps.pdf>

3. For how to install the tag, check from below link:

<http://beseencontrol.com/K80LR/3.HowToInstallTag.pdf>

4. For the keypad device, normally use it's NO and COM wire to open barrier/lock, for it's detail manual, check from below link:

<http://beseencontrol.com/K80LR/2.Keypad-Manual.pdf>