

[Quick Program guide]

email: be.seen@hotmail.com

skype: [pablochen.1996](https://www.skype.com/people/pablochen.1996)

Thank you very much for placing an order. If you have any questions or concerns, **please refrain from returning our products directly, as it would result in significant losses for us.**

We take pride in delivering high-quality products and excellent service support. **By giving us the opportunity to assist you, we can add substantial value** to your project and help you save significantly.

CREATE SECURITY FOR YOU

Contents

1. Quick Trial	2
1.1 Enroll Card/Key fob.	2
1.2 Enroll PIN Code/Password.	2
2. Official Do program for all users	3
2.1 Want to delete all users and start from Fresh.....	3
2.2 About user ID Number(4-digits)	3
2.3 How to Delete Card user.....	3
2.4 How to Delete PIN/Password Code.....	4
3. Want to change the default program code.....	4

1. Quick Trial

After wire and power on the system (**we have detail wire diagram and video for how to wire**), Now we can do a **quick trial**.

1.1 Enroll Card/Key fob.

press: **# 123456 #** -- this is to enter programming mode
then press: **1** -- this is to add card/fob user
then swipe card or Key Fob(Can swipe multiple cards/fobs)
then press: **#** ,now programming done.

You can now swipe the card/fob to open lock

1.2 Enroll PIN Code/Password.

For example,

John is the user, his user ID is: **20**(as **0020**, 4 digits user ID), Password is: 9089
the operation on keypad controller is:

press: **# 123456 #** -- this is to enter programming mode

then press: **23** -- **this is to add PIN user**

then press: **0020 9089 #**

(0020 here is user ID number-4 digits, 9089 here is pin code)

Now program done.

Now press 9089 # , can open lock.

Video check:<https://vimeo.com/917020352/c5a83e28fe>

2. Official Do program for all users

2.1 Want to delete all users and start from Fresh

Previously, maybe do some trial, now do official program, suggest that remove all users and begin from fresh stage, **the steps** are:

Press: # 123456 # (enter programming mode)

Press: 40 0 0 0 0 #

Now all enrolled users deleted

2.2 About user ID Number (4-digits)

Kindly Notes: Possibly a person will not work for you in future, you need to delete his/her open privilege. When do the enroll programming, we suggest you assign unique user ID number for each user and save these information, it will be easy to delete user in the future. For example, the format can be:

John(user ID Number: 0001)

Peter(user ID Number: 0002)

...

Chris(User ID number:0098)

...

Mary(user ID Number: 0101)

2.3 How to Delete Card user

press: # **123456** # -- this is to enter programming mode

then press: **41**

then swipe card or Key Fob(Can swipe multiple cards/fobs)

then press: # ,now programming done.

Now this card user has been deleted.

Video check:<https://vimeo.com/951785586/812cbad733>

2.4 How to Delete PIN/Password Code

For example, have user: Chris, Assigned user ID Number: 0098,

If some day in future, need to remove Chris's open privilege:

Press: # 123456 # (enter programming mode)

press 42 (to delete user)

press 0098# (**0098 here is user ID Number**)

with above steps, the user Chris(which user ID=0098) will be deleted.

3. Want to change the default program code

Firstly, enter programming mode by: # Master code #, 123456 is the default master code

then press: 0 new code # new code #

for example, new code is: 987654, you should: 0 987654 # 987654 #

If forget the program Master code, follow below to reset:

<https://vimeo.com/927014349/0a9866718b>