


## FAQ and details answers

If any questions, please: send email to: [947243303@QQ.com](mailto:947243303@QQ.com) or [be.seen@hotmail.com](mailto:be.seen@hotmail.com)  
Or add skype: pablochen.1996 ( there is a dot before 1996)

### 1. Only I can enter menu, How to prevent others enter menu?


Answer: When you register yourself, select **Privilege role** as “manager”, then when enter menu, need to verify your fingerprint or card. Others can't enter because they can't pass the verification. Fingerprint device picture as below:



### 2. For admin/manager how to enter menu? the steps are:

Press “MENU”

The device will display "Menu Login"



now punch your fingerprint,  
after verification passed, will enter menu.

### 3. How to enroll fingerprint?

- Press "MENU"
- The first one "Register",press "OK"
- Select "Register",press "OK"
- New Reg. press "OK"
- Press "4",
- Punch the same finger 3 times
- After success, press "ESC" to quit.

### 4. How to delete user?

- Press "MENU"
- The first one "Register",press "OK"
- Select "Register",press "OK"
- Select your want deleted user"ID". press "OK"
- Press "8",then press "OK".
- After success, press "ESC" to quit.

### 5. I forget admin/manager password or fingerprint, I can't enter menu now, how do do?

Press "MENU"

then press 999999999( totally nine 9), then press OK

then input: 89300316, press OK

you can enter menu now, please remove the admin/manager user